


# COMPLETED KICK OUT FLASHING AT ROOF / WALL TERMINATION

WM-RA 4.6



DO NOT INSTALL THE GUTTER SYSTEM UNTIL THE WM-RA EIFS SYSTEM HAS BEEN COMPLETED